

|              |                               |                                     |                                                         |                                                |
|--------------|-------------------------------|-------------------------------------|---------------------------------------------------------|------------------------------------------------|
| <b>PROEL</b> | <b>BOM</b><br>Spare Part List | <b>Part List:</b><br>96SPLKFLASH5V2 | <b>Description:</b><br>SPARE PART LIST KIT FLASH5A-5PV2 | Date: 02/10/2014<br>Ver.: A<br>Cmp.: G.BOCCATO |
|--------------|-------------------------------|-------------------------------------|---------------------------------------------------------|------------------------------------------------|

| Ordering Code   | Part Description                    | Note                                               |
|-----------------|-------------------------------------|----------------------------------------------------|
| —               | NOTE                                | ALL PARTS MARKED BY (*) CAN BE USED AS SPARE PARTS |
| —               |                                     | FOR OLDER FLASH5 MODELS                            |
| 91INT022        | MICRO.PUSH.BUTTON.MOD.PS909L-22.+ K | (gnd lift)(mid/nearfield)                          |
| 96ASP00181      | FLASH5AV2 AMPLIF. ASS'Y 120V/240V   | (*) complete amplifier module                      |
| 96CBA10003      | SPEAKER CABLES ASS'Y FOR FLASH5AV2  | (*)                                                |
| 96DIO0001       | 2W02G 200V 2A DIODE BRIDGE WOG      |                                                    |
| 96DIO0402       | KBL02 200V 4A DIODE BRIDGE KBL      |                                                    |
| 96DIS0007       | S1M 1000V 1A RECT.DIODE SMA         |                                                    |
| 96DIS3056       | 5.6V 1/2W ZENER DIODE SMD SOD-123   |                                                    |
| 96DIS3110       | 11V 1/2W ZENER DIODE SMD SOD-123    |                                                    |
| 96DIS4149       | 1N4148WS 75V 0.2A REC.DIODE SOD-323 |                                                    |
| 96ICL0010       | NJM7815FA 15V 1A POS. REG. T0220F   |                                                    |
| 96ICL0011       | NJM7915FA 15V 1A NEG. REG. T0220F   |                                                    |
| 96ICL0013       | TDA7293V 100W AUDIO AMPLIFIER M-15V |                                                    |
| 96ICL0021       | MC7812 12V 1A POS.REGULATOR T0220   |                                                    |
| 96ICL1015       | TL074CD QUAD OP.AMP. SOIC14         |                                                    |
| 96ICL1031       | IRS2092SPFB CLASS D DRIVER SOIC16   |                                                    |
| 96LED2003       | LT9911 PERKINELMER OPTOCOUPLER      |                                                    |
| 96MAN0101       | FLASH5AV2/FLASH5PV2 USER'S MANUAL   |                                                    |
| 96MEF00185      | 28x28MM PROEL LOGO PLATE WARMGREY10 | black logo                                         |
| 96MEF00190      | 28x28MM PROEL LOGO PLATE WHITE      | white logo                                         |
| 96METFLASH5AV2B | BLACK SPEAKER GRID FOR FLASH5AV2    |                                                    |
| 96METFLASH5AV2W | WHITE SPEAKER GRID FOR FLASH5AV2    |                                                    |
| 96PCAAFLASH5AV2 | FLASH5AV2 SUPPLY & AMPLIFIER PCBA   | active version (NOT TESTED)                        |
| 96PCAGFLASH5PV2 | FLASH5PV2 XOVER PCBA                | (*) passive version                                |
| 96PCAIFLASH5AV2 | FLASH5AV2 INPUT & FILTER PCBA       | active version (NOT TESTED)                        |
| 96PLA00101      | FLASH5 REAR CABINET BLACK           |                                                    |
| 96PLA00102      | FLASH5 FRONT CABINET BLACK          |                                                    |
| 96PLA00112      | RUBBER FOOT D=9MM H=9MM             |                                                    |
| 96PLA00113      | FLASH5 REAR CABINET WHITE           |                                                    |
| 96PLA00114      | FLASH5 FRONT CABINET WHITE          |                                                    |
| 96PLA10036      | KNOB BLK/WHT D=16MM H=14MM EVR      | (level)                                            |
| 96PRH0001       | HOR.ROT.POT.10KB RC00719            | (level)                                            |
| 96PRJ119        | JACK HORIZONTAL SLIM SOCKET         |                                                    |
| 96PRJ120        | HORIZONTAL DUAL RCA BLACK SOCKET    |                                                    |
| 96PRM005        | SOCKET 6A 250V IEC320+SWITCH        |                                                    |
| 96PRM014        | ROTARY VOLTAGE SWITCH 120V/240V     |                                                    |
| 96PRW001        | R/B PUSH TERMINAL HUANDA HD-603     | passive version                                    |
| 96PRX101        | XLR HOR FEMALE SOCKET LX-1604HP-3   |                                                    |
| 96TRF100011     | FLASH5AV2 TOROIDAL TRANSF. 115/230V |                                                    |
| 96TRMN0019      | IRF640 200V 11A N-MOS T0220 GDS     |                                                    |
| 96TRN1003       | MMBT5550 140V 0.6A NPN BJT SOT23BEC |                                                    |
| 96TRP1003       | MMBT5401 150V 0.6A PNP BJT SOT23BEC |                                                    |
| 98ALF5V2WZ16    | SPEAKER 5" 160HM FLASH5PV2          | (*) woofer for passive version                     |
| 98ALF5V2WZ4     | SPEAKER 5" 40HM FLASH5AV2           | (*) woofer for active version                      |
| 98DRF5V2WZ8     | TWEETER 1" 80HM FLASH5A/PV2         | (*) tweeter for both version                       |