BEAMZ MADE EAZY

155.134_155.135 V1.0

# SFP300T & SFP400T

# QUICK START GUIDE

# CONTROL MENU

| MENU | | DESCRIPTION |
|---|---|---|
| DMX ADDRESS | 001-512 | Press ENTER to edit. Use UP/DOWN to adjust. Press ENTER again to save. |
| CONTROL MODE | DMX | Slave mode: Receives DMX signals from console or master. |
| | Jump | Master mode: Auto-run and send DMX signals to slaves. |
| | Fade | |
| | Pulse | |
| | Sound | |
| | Manual | Master mode: Run manual data and send DMX signals to slaves. |
| | Knob | Master mode: Run knob mode and send DMX signals to slaves. |
| CHANNEL MODE | 6CH/4CH/3CH/2CH | See channel table for details. |
| AUTO SPEED | Adjusts auto-run speed for Jump and Pulse modes. | 0-100 (Slow-Fast) |
| MANUAL | Manual settings | See manual control section |
| DMX HOLD | ON | Maintain when there is no DMX signal |
| | OFF | Clear when there is no DMX signal |
| SCREEN FLIP | OFF | The screen displays normally |
| | ON | Inverts screen display. |
| LANGUAGE | CHINESE | Select display language. |
| | English | |

**MANUAL CONTROL**

This interface controls the fixture directly (DMX signals are ignored).

| CHANNEL | FUNCTION | VALUE | DESCRIPTION |
|---|---|---|---|
| 1 | DIMMER | 000-255 | Master dimming |
| 2 | STROBE | 000-255 | Strobe speed |
| 3 | WARM WHITE | 000-255 | Warm white dimming |
| 4 | WHITE | 000-255 | White dimming |

# DMX CHANNELS

## 2 CHANNELS

| CHANNEL | FUNCTION | VALUE | DESCRIPTION |
|---|---|---|---|
| 1 | DIMMER | 000-255 | Master dimming. |
| 2 | COLOR TEMPERATURE | 000 | No function. |
| | | 001-255 | Color temperature adjustment (low to high). |

## 3 CHANNELS

| CHANNEL | FUNCTION | VALUE | DESCRIPTION |
|---|---|---|---|
| 1 | DIMMER | 000-255 | Master dimming. |
| 2 | | 000-255 | Warm white dimming. |
| 3 | | 000-255 | White dimming. |

## 4 CHANNELS

| CHANNEL | FUNCTION | VALUE | DESCRIPTION |
|---|---|---|---|
| 1 | DIMMER | 000-255 | Master dimming. |
| 2 | | 000-255 | Warm white dimming. |
| 3 | | 000-255 | White dimming. |
| 4 | STROBE SPEED | 000 | No function. |
| | | 001-255 | Strobe speed adjustment (slow to fast). |

## 6 CHANNELS

| CHANNEL | FUNCTION | VALUE | DESCRIPTION |
|---|---|---|---|
| 1 | DIMMER | 000-255 | Master dimming. |
| 2 | | 000-255 | Warm white dimming. |
| 3 | | 000-255 | White dimming. |
| 4 | STROBE SPEED | 000 | No function. |
| | | 001-255 | Strobe speed adjustment (slow to fast). |
| 5 | MACRO SPEED | 000-255 | Macro speed (slow to fast). |
| 6 | COLOR | 000-004 | No function. |
| | | 005-010 | Color1 |
| | | 011-016 | Color2 |
| | | 017-022 | Color3 |
| | | 023-028 | Color4 |
| | | 029-034 | Color5 |
| | | 035-040 | Color6 |
| | | 041-046 | Color7 |
| | | 047-052 | Color8 |
| | | 053-058 | Color9 |
| | | 059-064 | Color10 |
| | | 065-070 | Color11 |
| | | 071-076 | Color12 |
| | | 077-082 | Color13 |
| | | 083-088 | Color14 |
| | | 089-094 | Color15 |
| | | 095-099 | Color16 |
| | | 100-149 | Jump mode. |
| | | 150-199 | Fade mode. |
| | | 200-249 | Pulse mode. |
| | | 250-255 | Sound mode. |

# BEAMZ

## YOUR FUTURE
## YOUR SKILLS
## YOUR PLATFORM
## YOUR PARTY
## YOUR EVENT

beamZ

is a leading developer of lighting products, including intelligent DMX moving heads, wireless battery operated DMX effects, static washes, sound-activated club effects, strobes & blacklights, LED lighting, fog and special effects machines, lasers and indoor and outdoor architectural lighting, as well as lighting controllers and protective bags.

BEAMZLIGHTING.COM