ANALOG INTERFACE AMPLIFIER

FREEWAY

Guía rápida

ATENCIÓN

- Lea por completo las instrucciones del aparato.
- Guarde las instrucciones del aparato.
- Preste atención a todas las advertencias.
- No utilice éste aparado junto a agua o en condiciones de gran humedad ambiente.
- No instale cerca de fuentes e calor como radiadores o disipadores.
- Limpie con una gamuza seca o levemente húmeda.
- Proteja el cable de alimentación de posibles tirones o pisotones.
- Desconecte el aparado durante tormentas eléctricas o cuando no vaya a ser usado por largos periodos de tiempo.
- No existen partes en el interior que puedan ser reparadas por el usuario. Cualquier operación en el interior del dispositivo debe ser realizada por personal cualificado.
- Se requerirá la intervención de un servicio técnico cuando el aparato se dañe de alguna forma, por ejemplo por sobretensiones, caídas, derrames de líquidos sobre el mismo o si es expuesto a lluvia o humedad.
- ATENCIÓN: Para reducir el riesgo de shock, no exponga el aparato a lluvia o humedad.
- Para más información o ante cualquier duda, consulte con el fabricante.

GARANTÍA

Triode Electronic Engineering S.L. garantiza este producto durante dos años desde su compra frente a defectos en materiales y procesos de manufactura bajo condiciones normales de uso.

La garantía ofrecida por Triode Electronic Engineering S.L. comprende la sustitución de piezas defectuosas que muestren evidencias de defectos, siempre que el producto sea devuelto a Triode Electronic Engineering S.L. en un plazo de dos años desde su compra.

Triode Electronic Engineering S.L. se reserva el derecho a realizar cambios en el diseño o realizar cualquier tipo de adición o mejora en este producto sin incurrir en obligación de instalar las mismas en productos fabricados previamente.

La garantía quedará anulada si se realizan operaciones en el interior del mismo por parte de una persona que no sea un técnico cualificado de Triode Electronic Engineering S.L.


La garantía quedará anulada si el dispositivo es alimentado con voltaje AC o fuera del rango especificado en este manual.

Para ejercer el uso de la garantía debe presentarse una prueba de compra.


Nombre del fabricante	Triode Electronic Engineering S.L.
Dirección del fabricante	C/ Gabriel Ciscar 23, CP. 02005 Albacete, España.
Nombre del producto	Freeway

EJEMPLOS DE CONEXIÓN

A un sistema PA o monitores FRFR para directo o ensayos
To a PA system or FRFR monitors for live show or rehearsal




DAW mode **OFF**
Speaker bypass **OFF**




Mixer / PA system

A un sistema PA o monitores FRFR para tocar en vivo o ensayar usando backing tracks / To a PA system or headphones for a live show or rehearsal using backing tracks




DAW mode **OFF**
Speaker bypass **OFF**



PC
Android/iOS

Mixer / PA system

Como interfaz de grabación principal
As a main studio recording interface




DAW mode **ON**




PC/iOS

Monitors/Studio

A una interfaz de grabación externa / To an external recording interface





DAW mode **OFF**



Recording interface

Usando un amplificador de guitarra y Freeeway como modelador de altavoces / To both a guitar amplifier and Freeway as a speaker modeler





Mixer


or




PC
Android/iOS

WIRING EXAMPLES


Como preamplificador, conectado a una etapa de potencia o al jack de retorno de efectos de un amplificador /As a preamp going into a power amp and speaker cabinet or the return jack of an amplifier




DAW mode **OFF**
Speaker bypass **ON**




Como preamplificador, conectado directamente a un modelador de altavoces externo / As a preamplifier going into an external speaker modeler




DAW mode **OFF**
Speaker bypass **ON**



Como modelador de altavoces DI para un amplificador de guitarra As a DI speaker modeler for a guitar amplifier



ANALOG SPEAKER MODELING OPTIONS



(1) *Pantalla / Cabinet*
- **ON** 4x12
- **OFF** 1x12

(2) *Micrófono / Microphone*
- **ON** SM57
- **OFF** E906

(3) *Altavoz / Speaker*
- **ON** Vintage 30
- **OFF** Greenback

(4) *Eje del micrófono / Microphone Axis*
- **ON** Off axis
- **OFF** On axis

Descarga el manual de usuario / Download the user manual

ANALOG INTERFACE AMPLIFIER

FREEWAY

Quick start guide

WARNING

- Read carefully this manual before use.
- Keep these instructions.
- Heed all warnings.
- Do not use this apparatus near water.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Clean only with dry cloth.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the device.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- No user serviceable parts inside. Refer all servicing to qualified service personnel.
- Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to ain or moisture, does not operate normally, or has been dropped.
- WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- Refer to labels on the unit, including bottom cover, or other markings and pertinent information.

WARRANTY

Triode Electronic Engineering S.L. warrants this product to be free from defects in materials and workmanship under normal use and service.

Thermion liability under this warranty is limited to repairing or replacing defective materials that show evidence of defect, provided the product is returned to Thermion with return authorization, where all parts and labor will be covered up to a period of two years.

The company shall not be liable for any consequential damage as a result of the product's use in any circuit or assembly.

Proof-of-purchase is considered to be the burden of the consumer.

Thermion reserves the right to make changes in design, or make additions to, or improvements upon this product without incurring any obligation to install the same on products previously manufactured.

The consumer forfeits the benefits of this warranty if the product's main assembly is opened and tampered with by anyone other than a certified Thermion technician or, if the product is used with voltages outside of the range suggested by the manufacturer.

Manufacturer name	Triode Electronic Engineering S.L.
Manufacturer Adress	C/ Gabriel Ciscar 23, CP. 02005 Albacete, Spain.
Product name	Freeway